



### Notes:

1. Place curb type sediment barriers on gently sloping street segments where water can pond and allow sediment to separate from runoff.
2. Sandbags, of either burlap or woven geotextile fabric, are filled with gravel.
3. Inspect and repair sediment barriers and remove sediment after each storm event. Sediment and gravel must be removed from the traveled way immediately.
4. Drop filters must be inspected often and emptied if needed.

NOT TO SCALE

CITY OF MILPITAS, ENGINEERING DIVISION

STANDARD DRAWING

CURB INLET SEDIMENT BARRIER  
SUMP CONDITIONS

NO. 470

ORIGINAL: 8/24/05  
DATE

APPROVED BY:

CITY ENGINEER

DATE: 8/24/05

SHEET 1 OF 1